

TOWER CASE

Value Series Mid-Tower Case

ATXCASEMID

Instruction Guide



Technical Support

The following technical resources are available for this StarTech.com product:

On-line help:

We are constantly adding new information to the *Tech Support* section of our web site. To access this page, click the *Tech support* link on our homepage, **www.startech.com**. In the tech support section there are a number of options that can provide assistance with this card.

Knowledge Base - This tool allows you to search for answers to common issues using key words that describe the product and your issue.

FAQ - This tool provides quick answers to the top questions asked by our customers.

Downloads - This selection takes you to our driver download page where you can find the latest drivers for this product.

Call StarTech.com tech support for help: **1-519-455-4931**
Support hours: Monday to Friday 9:00AM to 5:00PM EST (except holidays)

Warranty Information

This product is backed by a two-year warranty. In addition StarTech.com warrants its products against defects in materials and workmanship for the periods noted below, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

Limitation of Liability

In no event shall the liability to StarTech.com Ltd. (or its officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of related to the use of the product exceed the actual price paid for the product.

Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Installing a Rear Fan

NOTE: Please refer to your fan manufacturer's installation procedures to ensure proper installation of the fan. Rear fans should be installed/configured so that the warm air from inside the case is being exhausted out of the computer.

1. Position your fan so that the screw holes on the fan are aligned with the screw holes on the back of the case.
2. Screw the fan into place, with the heads of the screws outside of the case.
3. Connect your fan to your motherboard as instructed by your fan and motherboard manufacturers instructions.

Removing the Expansion Slot Covers

You will need to remove an expansion slot on the back of your computer when you want to add a FireWire card, sound card, etc. to your computer.

1. Remove one of the expansion slot covers by tapping it forcefully towards the inside of the case.
2. Install your expansion card as directed by the manufacturer.

Powering Your Computer

1. Make sure that the red voltage indicator at the back of your computer is in the proper position (115V for North America and 230V for most European countries).
2. Plug one end of the power cord into the computer and the other into an available wall socket.

Table of Contents

Introduction	2
Assembling Your Computer	3
Technical Support	7
Warranty Information	7

Product Specifications

Dimensions	7.87 (w) x 18.9 (l) x 17 (h) in.
Weight	20 lbs.
Power Supply	300 Watt 12V ATX
Power Supply Connectors	5 x 4-pin LP4 female 2 x small internal power 1 x 20-pin ATX motherboard adapter 1 x 4-pin extended ATX power 12V 1 x Aux plug for Pentium 4
Power Supply Certification	CSA, UL, FCC, CE, TUV
Motherboards Accepted	12.0 x 9.6 in. Standard ATX (including P4)
Expansion slots	Seven
Bays	Four external 5.25" Two external 3.5" Two internal 3.5"
LEDs	Power (Green) Hard drive activity (Yellow)

Introduction

Thank you for purchasing a StarTech.com value series mid-tower computer case. The convenient tool-less entry allows you to build and update your computer system with ease. With a total of four 5.25" and four 3.5" drive bays, there is ample room to expand and customize your system to suit your needs. This case includes a StarTech.com 300 Watt Pentium 4-compliant ATX 12V power supply and is constructed from 0.8 mm steel to ensure rugged reliability.

Features

- Allows easy access for building and upgrading your PC through tool-less design
- Provides four external 5.25" drive bays, two external 3.5" drive bays, and two internal 3.5" drive bay to allow for system customization
- Includes reliable StarTech.com 300 Watt ATX 12V power supply
- Easily-removable front bay panels
- Comes with large front-panel vents to ensure peak performance and stable operation
- Backed by StarTech.com's two-year warranty

Before You Begin

To ensure a quick and easy case assembly, please read through this section carefully before attempting to assemble your computer.

WARNING: Do not attempt to install any computer components with the system plugged in. **Never open your computer case when your system is turned on. Always make sure that the computer is off and unplugged before attempting to assemble or alter your computer.** Computer equipment can also be severely damaged by static electricity. Be sure that you are properly grounded before opening your computer case or touching any components. StarTech.com recommends that you wear an anti-static strap when installing any computer equipment. If an anti-static strap is unavailable, discharge yourself of any static electricity build-up by touching a large grounded metal surface (such as the computer case) for several seconds. Also be careful to handle cards and motherboards by their edges and not the gold connectors.

Contents

This package should contain:

- 1 x ATXCASEMID value series computer case with 300 Watt ATX 12V power supply
- 1 x power cord
- Assorted screws, buffers, and motherboard standoffs

3. Slide the disk drive into place, making sure that it is flush with the front panel of the computer and that the screw hole on the disk drive lines up with the holes and slots in the bay.

4. Screw the disk drives to the bay.

NOTE: If you wish to secure your disk drives from both sides, remove the right panel of the computer case using the procedure described on page 3 to access the right side of the bay.

5. Connect your disk drive to your motherboard and power supply as directed in their respective installation guides.

6. Repeat Steps 1 to 5 for any other disk drives you want to install.

Installing a Hard Disk Drive

NOTE: Please refer to your hard disk drive manufacturer's installation procedures to ensure proper installation of the drive.

The hard disk bracket is the section of the 3.5" bracket that does not have a removable front panel.

1. Slide your hard disk drive into the bracket, making sure that the screw holes on the hard disk drive are aligned with the screw holes and slots in the bracket.

2. Screw the hard disk drive to the bracket.

NOTE: To secure your hard disk drive from both sides, remove the right panel of the case using the procedure described on page 3 to access the right side of the bracket.

3. Connect your hard disk drive to your motherboard and power supply as directed in their respective installation guides.

Installing a Front Fan

NOTE: Please refer to your fan manufacturer's installation procedures to ensure proper installation of the fan.

1. Remove the black plastic fan frame from inside the computer by releasing the retaining tabs.

2. Slide the fan into the frame until it snaps into place.

3. Clip the frame back onto the front of the computer by lining up the tabs on the frame with the clip holes on the computer case and pressing firmly.

4. Connect your fan to your motherboard as instructed by your fan and motherboard manufacturers.

Installing Your Motherboard

NOTE: Please refer to your motherboard manufacturer's installation procedures to ensure proper installation of your motherboard.

1. Open your case using the procedure on page 3.
2. If your motherboard comes with an input/output panel (the collection of ports on the back of your system) that is different than the panel provided by StarTech.com, remove the StarTech.com input/output panel by firmly pressing it from the outside until it pops free. Insert the new input/output panel according to the manufacturer's instructions.
3. Align the motherboard so that the slots and ports on the board line up with the card brackets and input/output panel along the back of the computer. Make note of and mark the holes in the case that line up with holes in the motherboard.
4. With the motherboard removed from the case, install the motherboard standoffs into the marked holes in the case.
5. Place your motherboard onto the standoffs and align the screw-holes.
6. Screw your motherboard to the standoffs making sure you place a red buffer between the motherboard and the screws.
7. Connect the power supply to the motherboard as directed by your motherboard manufacturer.
8. Attach the LED connectors (multi-colored ribbon) to your motherboard as directed by your motherboard manufacturer.
9. Attach the power-on switch cable (orange and white wires) to your motherboard as directed by your motherboard manufacturer.
10. Attach the speaker cable (red and black wires) to your motherboard as directed by your motherboard manufacturer.

Installing Your Floppy and CD Drives

NOTE: Please refer to your disk drive manufacturer's installation procedures to ensure proper installation of the drive.

Depending on the size of your floppy disk drive, you will install it in either the 3.5" bays located just below the hard disk drive, or the 5.25" bays located near the top of the case. Your CD drive will be installed in one of the 5.25" drive bays.

1. Remove a plastic bay cover from the case.
2. Beneath the plastic bay cover is a thin plate of metal that has been perforated around the edges. Remove this plate by working it back and forth until it completely snaps off.

Requirements

This case does **not** include any hard or floppy disk drives, motherboards, sound cards, fans, USB/FireWire cards or any other computer component not listed above. You will need to supply these components yourself.

Assembling Your Computer

NOTE: This section is intended as a guide only. When installing computer components, be sure to refer to the manufacturer's installation documentation before attempting to install the parts.

Removing the Cover from Your Case

1. Make sure that the case is not plugged in and that you are properly grounded.
2. Gently lay the case on its right side.
3. Remove the thumbscrews from the back of the side panel and slide the panel towards the back of the computer until it stops, then lift up from the case.

Closing Your Case

1. Position the panel so that the screw holes are aligned with the back of the computer.
2. Gently slide the panel into the case until it is firmly in place. Make sure that the ridges on the back and sides of the panel are properly aligned with the computer case.
3. Secure the panel in place using the thumbscrews.